



FloorShark® 170TFG

Textured Floor Graphic Polyester Film

Applications

- Indoor floor graphic displays
- Supermarkets, shopping malls, convention centres, airports
- All smooth hard floors e.g. concrete & tiling
- Low Pile Carpet tiles

Benefits

- Unique sharkskin coating absorbs the ink & dries tough
- Eliminates the need to laminate
- Sharkskin structure gives great color gamut and high grip; R10 certified
- Easy to apply & easy to remove, does not tear into small pieces when removing
- No shrinkage - no risk of a rim of dirty adhesive forming around the print
- Ultra-tough polyester base, resists tearing, resists pallet trucks & stiletto heels



**Certified for
HP Latex Inks**

Post Printing Information for Latex & Solvent Inks:

As with all filmic media, this product must be allowed to “gas-out” after printing. This can be achieved by leaving the prints face up, ideally 24 hours, to set and harden the unique scratch resistant properties. If unable to do this e.g. with a long print run, after printing the roll stand it vertically and loosely unwind as much as possible, to allow air in and gases out.

Recommended Conditions:

Printroom	15°C - 30°C	30% - 65% RH
Usage	-40°C - 80°C	10% - 90% RH
Storage	10°C - 20°C	20% - 50% RH

Printability:



Thickness:

170 μ	6.7 mil	224 gsm
-----------------	-------------------	-------------------

Available widths:

1372 54"	1524 60"
--------------------	--------------------

Adhesion:

AFTER 24H 16 N /25mm



KERNOW COATINGS | Kernick Road | Penryn | Cornwall | TR10 9DQ | UK

www.kernowcoatings.com | sales@kernowcoatings.com | T: +44 (0)1326373147

Registered in England | No. 1092182 | A Member of the Sensitiser Group of Companies

Installation Instructions

FloorSharK is an ultra-tough polyester film with zero stretch, enabling very accurate panel joints.

Installation must be undertaken as follows.

Smaller panels are very quick and easy to apply without special technique but if covering a much larger area, with multiple panels several metres long, the following technique is strongly recommended.

If covering a very large area, have your designer split the panels on the shorter length e.g. if a 4m x 9m area, each panel should be 4m long plus bleed.

The floor must be clean, dry, smooth and all dust and debris removed. Lay out the entire floor graphic and apply with masking tape in the **exact** position required. Allow at least 20 cm bleed all round if covering a full floor area e.g. a plinth at a trade show and cut the excess after installation.

If applying in multiple panels, start on the left side and apply this panel first. Use 8cm overlap joints.

Create a tape hinge in the centre of the panel – two overlapping lines of masking tape required, ensuring this hinge is firmly taped to the floor.

Then tape 50% of the graphic down at the edges to ensure the graphic cannot move, flip the other 50% of the panel over and remove the liner up to almost the tape hinge.

Carefully cut the liner with a sharp scalpel and discard.

Then lift the graphic and flip it over, keeping the adhesive from contacting the floor.

Hold at circa 25 degrees to the floor and keep a firm tension, whilst a colleague uses a 15-20 cm squeegee to apply the graphic to the floor. Use light and steady pressure and each stroke **must be at 90 degrees to the run of the graphic**.

Installation is very quick, easy and incredibly accurate but only if this hinge and squeegee method is used; ensuring perfect joins in the final printed artwork.